

Date: July 2021



SPECIFICATION

Surface Mounted Paper Towel Dispenser shall hold and dispense standard multi-fold or standard C-fold paper towels and shall be fabricated of 304 stainless steel, finished in matte black powder coat. Towel dispensing slot shall have a fully hemmed-in rolled edge for snag free dispensing and user safety. Dispenser door shall be held close with a tumbler lock. Unit shall be provided with refill viewer slot on side panels. Back of unit shall have keyhole slots for hanging on pre-installed screws (by others).

INSTALLATION

Unit is surfaced mounted on wall or partitioned using four No. 10 self tapping screws (supplied by others). Four mounting holes through back are "keyhole" slots for ease of installation on pre-installed screws. For mounting height standards refer to current Building Code of Australia for able bodied and/or disabled use.

OPERATION

Towels are self-feeding until supply is depleted. Unit may be refilled with a partial load in-place and will continue to feed properly. Low level of towel supply is indicated from 25% capacity empty.

WARRANTY

One year.

Surface Mounted Paper Towel Dispenser – Matte Black shall be Model No. 10-0210-41 as supplied by ASI JD MacDonald.

 All ASI JD MacDonald disabled compliant products when installed must be in accordance with AS1428 to ensure the specified product is complying with all washroom specification requirements.

